



Parts identification




































■ Turntable (SP-15)




■ Turntable base (SH-15B1)




“Warning: To prevent fire or shock hazard, do not expose this appliance to rain or moisture.”



■ System tonearm (EPA-500)
Arm base/EPA-B500



■ Arm unit/EPA-A501H



■ Stylus pressure gauge/SH-50P1

